

Reverse Osmosis System Maintenance Checklist



This checklist covers all the maintenance tasks that you should routinely perform on your reverse osmosis system.

Every 6-12 Months

- ☐ Change sediment pre-filter(s)
- ☐ Change block and granular carbon pre-filter(s)
- ☐ Clean and/or sanitize system
- ☐ Check storage tank pressure is within 6-8 psi when empty

Every 12 Months

- ☐ Clean and sanitize your RO system
- ☐ Change carbon post-filter
- ☐ Change remineralization post-filter

Every 2-5 Years or When TDS Rejection Drops Below 80%

- ☐ Change RO membrane

Optional: Every Couple of Weeks

- ☐ Drain the reverse osmosis storage tank and let it refill
- ☐ Control permeate water TDS